VDR

Remote Control Keys

Key	Normal	VDR	Channels
Up	Ch up	Crsr up	Crsr up
Down	Ch down	Crsr down	Crsr down
Left	Prev group	-	Page up
Right	Next group	-	Page down
Ok	Ch display	Select	Switch
Menu	Menu on	Menu off	Menu off
Back	-	Menu off	VDR menu
Red	-	Record	Edit
Green	-	Language	New
Yellow	-	Pause live	Delete
Blue	-	Stop/Resume	Mark
0..9	Ch select	-	-

Key	Timers	Edit/New	Recordings	Replay
Up	Crsr up	Crsr up	Crsr up	Play
Down	Crsr down	Crsr down	Crsr down	Pause
Left	Page up	Decrement	Page up	Search back
Right	Page down	Increment	Page down	Search forward
Ok	Edit	Accept	Play	Progress disp.
Menu	Menu off	Menu off	Menu off	Menu on
Back	VDR menu	Discard	VDR menu	Recordings menu
Red	Edit	ABC/abc	Play/Commands(2)	Jump
Green	New	Ins/Ovr	Rewind	Skip -60s
Yellow	Delete	Delete	Delete	Skip +60s
Blue	On/Off(1)	-	Summary	Stop
0..9	-	Numeric inp.	Exec cmd(2)	Editing

Replay Control

```
- Up      Resumes normal replay from any "pause", "forward" or
          "backward" mode.
- Down    Halts playback at the current position. Press again
          to continue playback.
- Blue    Stops playback and stores the current position, so that
          playback can be resumed later at that point.
- Left
  Right   Runs playback forward or backward at a higher speed; press
          again to resume normal speed. If in Pause mode, runs
          forward or backward at a slower speed; press again to
          return to pause mode. Pressing and holding down the button
          performs the function until the button is released again.
          If "Multi Speed Mode" has been enabled in the "Setup" menu,
          the function of these buttons changes in a way that gives
          you three fast and slow speeds, through which you can
          switch by pressing the respective button several times.
- Red     Jump to a specific location. Enter the time you want to
          jump to and then press "Left" or "Right" to jump relative
          to the current position, "Up" to jump to an absolute
          position, and "Down" to jump and pause at an absolute
          position.
- Green
  Yellow  Skips about 60 seconds back or forward.
          Pressing and holding down the button performs the function
          until the button is released again.
- Ok      Brings up the replay progress display, which shows the
          date, time and title of the recording, a progress bar and
          the current and total time of the recording.
          Press "Ok" again to turn off the progress display.
- Back    Stops replaying and brings up the "Recordings" menu. This
          can be used to easily delete a recording after watching it,
          or to switch to a different recording.
```

Editing a Recording

```
- 0       Toggles an editing mark. If the mark indicator shows a red
          triangle, the current mark is deleted. Otherwise a new
          mark is set at the current position.
- 4, 6    Move an editing mark back and forward. You need to first
          jump to an editing mark for this to work.
- 7, 9    Jump back and forward between editing marks. Replay goes
          into still mode after jumping to a mark.
- 8       Positions replay at a point 3 seconds before the current
          or next "start" mark and starts replay.
- 2       Start the actual cutting process.
```

DVD mode

```
- Red     Goto position (enter time)
- Green   1 min. backward
- Yellow  1 min. forward
- Blue    Goto title (enter title number)

- Back    Stop Replay - Exit

- Ok      toggle progess display (this will mess up any subtitles)
- 8/0     Move Menu Up/Down (only if progess display on)

- Up,
  kPlay   playback
- Down,
  kPause  pauses playback

- Left,
  Right,
  kFastRew,
  kFastFwd rewind/forward (fast if play mode, slow if pause mode)

- 1       skip to next audio channel
- 2       skip to next subtitle ( if "no subtitle" is reached,
          progress display on )
- 3       skip to next angle

- 4       skip to previous chapter
- 6       skip to next chapter
- 7,
  kChanDn skip to previous title
- 9,
  kChanUp skip to next title

- 5       DvdNavigationForce ON / go to DVD Root menu (if progess
          display on)
- 8       go to DVD Title menu      (only avaiable if progess
          display off)
- 0       go to DVD Audio menu      (only avaiable if progess
          display off)

In DVD-Menu:
2/8/4/6,5 DVD menu Up/Down/Left/Right, OK control's
          Left/Right/Up/Down OK also work when in menuspace
          Red      Leave DvdNavigationForce
          Green    skip to previous title
          Yellow   skip to next     title
          Goto title (enter title number)
```

VCD mode

```
- Down    Pause
- Left    Fast backward when in 'Play' mode (ISO62107 SVCDs only)
          Slow motion undefined yet (should fall back into slow fwd)
- Right   Slow motion when in 'Pause' mode
          Fast forward when in 'Play' mode
- 1       Skip to previous VCD entry
- 3       Skip to next VCD entry
- 4       Skip to previous VCD track
- 5       Skip to beginning of current track
- 6       Skip to next VCD track
- Ok      Turn progress bar on/off
- Red     Time search in units of CD-ROM MSF (see above)
- Green   Skip -60s
- Yellow  Skip +60s
```

SVCDs may contain MPEG data with two audio channels. If a second audio channel is available, VDR's toggle mechanism for audio channels will be enabled.

The 'Yellow' key in the VideoCD menu will eject the disc loaded in /dev/cdrom.

The 'Blue' key in the VideoCD menu will be enabled if the (S)VCD contains also 'segment play items'. These can be up to 1980 still images or audio/video clips placed in the (S)VCD's data track.

The viewer can be controlled with the following keys:

```
- 4       Skip to previous item.
          Skip to first segment of multisegment items.
- 5       Toggle between low and high resolution of still images.
- 6       Skip to next item.
```

Version 0.0.6 of the plugin introduces PSD controlled replay mode. This can be enabled in the setup and defines yet the following keys for replay control as required by the PSD menus:

```
    1..9:    Goto NUMERIC selection.
    Ok:      Goto DEFAULT selection.
    Left:    Goto PREVIOUS selection.
    Right:   Goto NEXT selection.
    Back:    Goto RETURN selection.
    Blue:    Stop (S)VCD replay.
```